

**BS2\_GetAllDeviceZoneAGEntranceLimit** ..... 1

..... 1

..... 1

..... 1

..... 1

## BS2\_GetAllDeviceZoneAGEntranceLimit

Ethernet Access Group 가 .

```
#include "BS_API.h"

int BS2_GetAllDeviceZoneAGEntranceLimit(vvoid* context, BS2_DEVICE_ID
deviceId, BS2DeviceZoneAGEntranceLimit** deviceZoneAGEntranceLimitObj,
uint32_t* numDeviceZoneAGEntranceLimit);
```

[BS2DeviceZoneAGEntranceLimit](#)

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *deviceZoneAGEntranceLimitObj* : device zone Access Group
- [Out] *numDeviceZoneAGEntranceLimit* : device zone Access Group

zoneObj	<a href="#">BS2_ReleaseObject</a>
---------	-----------------------------------

BS\_SDK\_SUCCESS , 가

- [BS2\\_GetAccessGroupEntranceLimit](#)
- [BS2\\_SetDeviceZoneAGEntranceLimit](#)
- [BS2\\_RemoveDeviceZoneAGEntranceLimit](#)

## BS2\_RemoveAllDeviceZoneAGEntranceLimit

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2\\_getalldevicezoneagentrancelimit&rev=1504568993](http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getalldevicezoneagentrancelimit&rev=1504568993)

Last update: **2017/09/05 08:49**