

BS2_SetRS485ConfigExDynamic 1

..... 1

..... 1

..... 1

..... 1

BS2_SetRS485ConfigExDynamic

[+ 2.9.9] CoreStation RS485 .

```
#include "BS_API.h"

int BS2_SetRS485ConfigExDynamic(void* context, uint32_t deviceId,
BS2Rs485ConfigEXDynamic* config);
```


: CoreStation 20(CS-20, CS-20P), Door Interface(DI-24)

[BS2Rs485ConfigEXDynamic](#)

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* : RS485

BS_SDK_SUCCESS , 가

[BS2_GetRS485ConfigExDynamic](#)



From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_setrs485configexdynamic

Last update: **2025/06/11 15:06**