Table of Contents

Configuration API > BS2_GetInputConfig

BS2_GetInputConfig

Retrieves input port settings from the device.

Declaration

```
#include "BS_API.h"

int BS2_GetInputConfig(void* context, uint32_t deviceId, BS2InputConfig*
config);
```

> See BS2InputConfig Structure

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *config* : Input port configurations pointer

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.