Table of Contents

Zone Control API > BS2_RemoveAllAccessGroupEntranceLimit

BS2_RemoveAllAccessGroupEntranceLimit

Removes all access group entrance limit

Declaration

```
#include "BS_API.h"

int BS2_RemoveAllAccessGroupEntranceLimit(void* context, BS2_DEVICE_ID
deviceId);
```

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

BS2_GetAccessGroupEntranceLimit
BS2_GetAllAccessGroupEntranceLimit
BS2_SetAccessGroupEntranceLimit
BS2_RemoveAccessGroupEntranceLimit