BS2_SetGlobalAPBViolationByDoorOpenHandler

Zone Control API > BS2_SetGlobalAPBViolationByDoorOpenHandler

BS2_SetGlobalAPBViolationByDoorOpenHandler

[+ 2.7.0]   .
            Global APB(BS2_SetCheckGlobalAPBViolationHandler   )
                            ,
Global APB By Door Open   , 2   .
1   ,   OnCheckGlobalAPBViolationByDoorOpen
                ,
2
OnUpdateGlobalAPBViolationByDoorOpen   .
                            OnUpdateGlobalAPBViolationByDoorOpen   update   .

```
#include "BS_API.h"

int BS2_SetGlobalAPBViolationByDoorOpenHandler(void* context,
OnCheckGlobalAPBViolationByDoorOpen ptrCheck,
OnUpdateGlobalAPBViolationByDoorOpen ptrUpdate);
```

> OnCheckGlobalAPBViolationByDoorOpen
> OnUpdateGlobalAPBViolationByDoorOpen

- [In] *context* : Context
- [In] *ptrCheck* :
- [In] *ptrUpdate* :

BS2AuthConfig   useGlobalAPB   true   ,
BS2DoorSensor   apbUseDoorSensor   true   .

                        BS_SDK_SUCCESS   ,
        .

[BS2_CheckGlobalAPBViolationByDoorOpen](#)

[BS2_CheckGlobalAPBViolationByDoorOpen](#)