Table of Contents

![Fix Me!] **This page is not fully translated, yet. Please help completing the translation.**
(remove this paragraph once the translation is finished)

Zone Control API > BS2_SetGlobalAPBViolationByDoorOpenHandler

BS2_SetGlobalAPBViolationByDoorOpenHandler

[+ 2.7.0] Registers callback function for global determination when an APB violation alarm occurs.
Generally, Global APB API BS2_SetCheckGlobalAPBViolationHandler determines access with the user authentication only.
On the other hand, Global APB By Door Open has two steps; i) User authentication ii) Actual access based on the door sensor.
First, OnCheckGlobalAPBViolationByDoorOpen is called after a user authentication.
Second, OnUpdateGlobalAPBViolationByDoorOpen is called after checking the door sensor to figure out if the user actually accessed the door.
The final status is updated through OnUpdateGlobalAPBViolationByDoorOpen

Declaration

```
#include "BS_API.h"

int BS2_SetGlobalAPBViolationByDoorOpenHandler(void* context,
OnCheckGlobalAPBViolationByDoorOpen ptrCheck,
OnUpdateGlobalAPBViolationByDoorOpen ptrUpdate);
```

> See OnCheckGlobalAPBViolationByDoorOpen Callback Function
> See OnUpdateGlobalAPBViolationByDoorOpen Callback Function

Parameter

- [In] *context* : Context
- [In] *ptrCheck* : Callback function called for global determination when Anti Passback alarm occurs
- [In] *ptrUpdate* : Callback function called for updating status of the authenticated user.

> **NOTE**
> To use Global Anti Passback service, set BS2AuthConfig
> useGlobalAPB = true,
> and BS2DoorSensor apbUseDoorSensor = true.

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

BS2_CheckGlobalAPBViolationByDoorOpen