Table of Contents

> BS2_GetDataEncryptKey

===== BS2_GetDataEncryptKey =====(Deprecated) Gets the encryption key for the device.

IMPORTANT
You are not able to retrieve a key value due to security reason.

Declaration

```
#include "BS_API.h"

int BS2_GetDataEncryptKey(void* context, uint32_t deviceId, BS2EncryptKey*
keyInfo);
```

> See BS2EncryptKey Structure

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *keyInfo* : The address of encryption key information structure to return

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

BS2_SetDataEncryptKey
BS2_RemoveDataEncryptKey