Table of Contents

SDK API > BS2_GetCredentialKeyInfo

BS2_GetCredentialKeyInfo

[+ V2.6.0] Gets the encryption key information for the device.

Declaration

```
#include "BS_API.h"

int BS2_GetCredentialKeyInfo(void* context, uint32_t deviceId,
BS2CredentialKeyInfo* keyInfo);
```

> See BS2CredentialKeyInfo Structure

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *keyInfo* : The address of structure that the encryption key information to be returned.

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

BS2_SetCredentialKeyInfo
BS2_RemoveCredentialKeyInfo