Table of Contents

USB Exported Control API > BS2_GetLogFromDirWithKey

BS2_GetLogFromDirWithKey

[+2.8.2] Gets the log after a given log record ID from the data extracted by USB by a maximum of amount.

Declaration

```
#include "BS_API.h"

int BS2_GetLogFromDirWithKey(void* context, const char* szDir, BS2_EVENT_ID
eventId, uint32_t amount, BS2Event** logsObj, uint32_t* numLog, const
BS2EncryptKey* key);
```

View the structure of BS2Event

Parameters

- [In] *context* : Context
- [In] *szDir* : Data storage path
- [In] *eventId* : Log record ID, if 0 then import from scratch.
- [In] *amount* : Maximum number of log records, if zero, gets all records since eventId.
- [Out] *logsObj* : Pointer to store the address of the log record
- [Out] *numLog* : Number of log records
- [In] *key* : Encryption key and the key value specified by BS2_SetDataEncryptKey

> 참**Note**
> The logsObj variable must be used and then returned to the system
> using the BS2_ReleaseObject function.

Return value

Returns BS_SDK_SUCCESS if performed successfully, or a corresponding error code if an error occurs.

Watch Together

BS2_GetUserDatabaseInfoFromDirWithKey
BS2_GetUserListFromDirWithKey
BS2_GetUserInfosFromDirWithKey
BS2_GetUserDatasFromDirWithKey
BS2_GetUserInfosExFromDirWithKey
BS2_GetUserDatasExFromDirWithKey
BS2_GetLogBlobFromDirWithKey
BS2_GetFilteredLogFromDirWithKey