Table of Contents

Configuration API > BS2_GetSystemExtConfig

BS2_GetSystemExtConfig

Retrieves Master and slave device encryption settings from the device.

Declaration

```
#include "BS_API.h"

int BS2_GetSystemExtConfig(void* context, uint32_t deviceId,
BS2SystemConfigExt* config);
```

See BS2SystemConfigExt Structure

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *config* : Master and slave device encryption settings pointer

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.