Table of Contents

USB Exported Control API > BS2_GetUserSmallDatasFromDir

BS2_GetUserSmallDatasFromDir

[+ 2.6.3] Gets the user information of the given user ID & usermask from USB exported data.
The only difference between with BS2_GetUserDatasFromDir which is using structure BS2UserBlob is that the 5th parameter BS2UserPhoto of BS2UserSmallBlob is using pointer for efficienct memory use.

Declaration

```
#include "BS_API.h"

int BS2_GetUserSmallDatasFromDir(void* context, const char* szDir, char*
uids, uint32_t uidCount, BS2UserSmallBlob* userBlob, BS2_USER_MASK
userMask);
```

See BS2UserSmallBlob Structure

Parameter

- [In] *context* : Context
- [In] *szDir* : Storage path in device
- [In] *uids* : User ID list trying to get
- [In] *uidCount* : Number of user ID
- [Out] *userBlob* : Pointer to store the user information
- [In] *userMask* : User Mask

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.

See Also

BS2_GetUserSmallInfosFromDir
BS2_GetUserSmallDatasFromDir
BS2_GetUserSmallInfosExFromDir
BS2_GetUserSmallDatasExFromDir

From:
http://kb.supremainc.com/bs2sdk./ - **BioStar Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2_getusersmalldatasfromdir&rev=1560326244

Last update: **2019/06/12 16:57**