Table of Contents

Configuration API > BS2_SetBarcodeConfig

BS2_SetBarcodeConfig

[+ V2.8] Stores configuration of Barcode of X-Station 2.

Declatation

```
#include "BS_API.h"

int BS2_SetBarcodeConfig(void* context, uint32_t deviceId, BS2BarcodeConfig*
config);
```

> See BS2BarcodeConfig

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *config* : Barcode configurations pointer

Return Value

If successfully done, BS_SDK_SUCCESS will be returned. If there is an error, the corresponding error code will be returned.