Table of Contents

USB Exported Control API

This API allows to control/manage USB Exported.

- BS2_AllocateUsbContext: Allocates context which manages & controls USB device.
- BS2_ReleaseUsbContext: Releases context which manages & controls USB device.
- BS2_GetUserDatabaseInfoFromDir: Gets total user information(Number of user/card/fingerprint/face) from USB exported data.
- BS2_GetUserListFromDir: Gets the enrolled user ID list from USB exported data.
- BS2_GetUserInfosFromDir: Gets the user information of the given user ID from USB exported data.
- BS2_GetUserDatasFromDir: Gets the user information of the given user ID & usermask from USB exported data.
- BS2_GetUserInfosExFromDir: Gets the user information of the given user ID from USB exported data. (Including Job, phrase)
- BS2_GetUserDatasExFromDir: Gets the user information of the given user ID & usermask from USB exported data. (Including Job, phrase)
- BS2_GetUserSmallInfosFromDir: [+ 2.6.3] Gets the user information of the given user ID from USB exported data.
- BS2_GetUserSmallDatasFromDir: [+ 2.6.3] Gets the user information of the given user ID & usermask from USB exported data.
- BS2_GetUserSmallInfosExFromDir: [+ 2.6.3] Gets the user information of the given user ID from USB exported data. (Including Job, phrase)
- BS2_GetUserSmallDatasExFromDir: [+ 2.6.3] Gets the user information of the given user ID & usermask from USB exported data. (Including Job, phrase)
- BS2_GetLogFromDir: Gets certain amount of logs from USB exported data.
- BS2_GetLogBlobFromDir: Gets certain amount of logs based on the event mask from USB exported data.
- BS2_GetFilteredLogFromDir: Gets filtered logs from USB exported data.
- BS2_GetLogSmallBlobFromDir: [+ 2.6.4] Gets certain amount of logs based on the event mask from USB exported data in an efficient way.