Table of Contents

Zone Control API > BS2_RemoveAllAntiPassbackZone

BS2_RemoveAllAntiPassbackZone

Removes all Anti Passback zones.

Declaration

```
#include "BS_API.h"

int BS2_RemoveAllAntiPassbackZone(void* context, uint32_t deviceId);
```

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

BS2_GetAntiPassbackZone
BS2_GetAllAntiPassbackZone
BS2_GetAntiPassbackZoneStatus
BS2_GetAllAntiPassbackZoneStatus
BS2_SetAntiPassbackZone
BS2_SetAntiPassbackZoneAlarm
BS2_RemoveAntiPassbackZone
BS2_ClearAntiPassbackZoneStatus
BS2_ClearAllAntiPassbackZoneStatus