Table of Contents

SDK API > BS2_RemoveDataEncryptKey

BS2_RemoveDataEncryptKey

[+ V2.6.0] Removes the encryption key for the device.
If function is called successfully, the device will revert to the default key value, and all data on the device will be erased.

Declaration

```
#include "BS_API.h"

int BS2_RemoveDataEncryptKey(void* context, uint32_t deviceId);
```

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

BS2_GetDataEncryptKey
BS2_SetDataEncryptKey