Slave Control API

Slave Control API

RS485   .

- [BS2_GetSlaveDevice](): RS485   .
- [BS2_SetSlaveDevice]:   /   /   .
- [BS2_GetSlaveExDevice]:   CoreStation   RS485
     .
- [BS2_SetSlaveExDevice]:   CoreStation   /   /
     .

> SDK
>   .

BS2Rs485SlaveDevice

```
typedef struct {
    uint32_t deviceID;
    uint16_t deviceType;
    uint8_t enableOSDP;
    uint8_t connected;
} BS2Rs485SlaveDevice;
```

1. *deviceID*
                  .

2. *deviceType*
                .

3. *enableOSDP*
                                flag   .

4. *connected*
                                flag   .

BS2Rs485SlaveDeviceEX

```
typedef struct {
    uint32_t deviceID;
    uint16_t deviceType;
    uint8_t enableOSDP;
```

```
    uint8_t connected;
    uint8_t channelInfo;
    uint8_t reserved[3];
} BS2Rs485SlaveDeviceEX;
```

1. *deviceID*

.

2. *deviceType*

.

3. *enableOSDP*

flag .

4. *connected*

flag .

5. *channelInfo*

Channel .

6. *reserved*

.