Table of Contents

BS2_SetScheduledLockUnlockZoneAlarm 1
Declaration 1
Parameter 1
Return Value 1
See Also 1

BS2_SetScheduledLockUnlockZoneAlarm

Configures the alarm status of the Scheduled Lock/Unlock zone.

Declaration

```
#include "BS_API.h"

int BS2_SetScheduledLockUnlockZoneAlarm(void* context, uint32_t deviceId,
uint8_t alarmed, uint32_t* zoneIds, uint32_t zoneIdCount);
```

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *alarmed* : Whether the alarm has been triggered or not
- [In] *zoneIds* : List of Scheduled Lock/Unlock zone IDs
- [In] *zoneIdCount* : Number of Scheduled Lock/Unlock zone IDs

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

BS2_GetScheduledLockUnlockZone
BS2_GetAllScheduledLockUnlockZone
BS2_GetScheduledLockUnlockZoneStatus
BS2_GetAllScheduledLockUnlockZoneStatus
BS2_SetScheduledLockUnlockZone
BS2_RemoveScheduledLockUnlockZone
BS2_RemoveAllScheduledLockUnlockZone

From:
http://kb.supremainc.com/bs2sdk/ - **BioStar Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_setscheduledlockunlockzonealarm

Last update: **2016/02/17 14:36**