

**BS2\_ClearAllDeviceZoneAccessRecord** ..... 1  
..... 1  
..... 1  
..... 1  
..... 1

[Zone Control API](#) > [BS2\\_ClearAllDeviceZoneAccessRecord](#)

---

## BS2\_ClearAllDeviceZoneAccessRecord

Ethernet

```
#include "BS_API.h"

int BS2_ClearAllDeviceZoneAccessRecord(void* context, uint32_t deviceId,
uint32_t zoneID);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zoneID* :

BS\_SDK\_SUCCESS , 가

[BS2\\_GetDeviceZone](#)  
[BS2\\_GetAllDeviceZone](#)  
[BS2\\_SetDeviceZone](#)  
[BS2\\_RemoveDeviceZone](#)  
[BS2\\_SetAntiPassbackZone](#)  
[BS2\\_RemoveAllDeviceZone](#)  
[BS2\\_SetDeviceZoneAlarm](#)  
[BS2\\_ClearDeviceZoneAccessRecord](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2\\_clearalldevicezoneaccessrecord&rev=1504534290](http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_clearalldevicezoneaccessrecord&rev=1504534290)

Last update: **2017/09/04 23:11**