

**BS2\_SetInterlockZoneAlarm**

.....

1

.....

1

.....

1

.....

1

.....

1

## BS2\_SetInterlockZoneAlarm

```
#include "BS_API.h"

int BS2_SetInterlockZoneAlarm(void* context, uint32_t deviceId, uint8_t
alarmed, uint32_t* zoneIds, uint32_t zoneIdCount);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *alarmed* :
- [In] *zoneIds* :                      zone id
- [In] *zoneIdCount* :                      zone id

BS\_SDK\_SUCCESS , 가

[BS2\\_GetInterlockZone](#)  
[BS2\\_GetInterlockZoneStatus](#)  
[BS2\\_GetAllInterlockZoneStatus](#)  
[BS2\\_SetInterlockZone](#)  
[BS2\\_RemoveInterlockZone](#)  
[BS2\\_RemoveAllInterlockZone](#)

From:  
<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:  
[http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2\\_setinterlockzonealarm&rev=1520397415](http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_setinterlockzonealarm&rev=1520397415)

Last update: **2018/03/07 13:36**