

**BS2\_FactoryReset** ..... 1  
..... 1  
..... 1  
..... 1

[Device API](#) > [BS2\\_FactoryReset](#)

---

## BS2\_FactoryReset

```
#include "BS_API.h"

int BS2_FactoryReset(void* context, uint32_t deviceId);
```

- [In] *context* : Context
- [In] *deviceId* :

BS\_SDK\_SUCCESS , 가

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

[https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2\\_factoryreset](https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_factoryreset)

Last update: **2018/02/06 10:37**