

Table of Contents

| | |
|--|---|
| BS2_CheckGlobalAPBViolationByDoorOpen | 1 |
| Declaration | 1 |
| Parameter | 1 |
| Return Value | 1 |
| See Also | 1 |

[Zone Control API](#) > [BS2_CheckGlobalAPBViolationByDoorOpen](#)

BS2_CheckGlobalAPBViolationByDoorOpen

[+ 2.7.0] Transfers Global APB by door open results to the device.

Declaration

```
#include "BS_API.h"

int BS2_CheckGlobalAPBViolationByDoorOpen(void* context, uint32_t deviceId,
uint16_t seq, int handleResult, uint32_t zoneID);
```

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *seq* : Packet sequence
- [In] *handleResult* : Global Anti Passback determination result(BS_SDK_SUCCESS or BS_SDK_ERROR_XXX)
- [In] *zoneID* : Global Anti Passback zone Id

NOTE

Packet sequence must be the same with the value from OnCheckGlobalAPBViolationByDoorOpen

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.

If there is an error, the corresponding error code will be returned.

See Also

[BS2_SetGlobalAPBViolationByDoorOpenHandler](#)

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_checkglobalapbviolationbydooropen

Last update: **2020/07/29 11:07**