

# Table of Contents

<b>BS2_GetInputConfig</b> .....	1
Declaration .....	1
Parameter .....	1
Return Value .....	1

[Configuration API](#) > [BS2\\_GetInputConfig](#)

---

## BS2\_GetInputConfig

Retrieves supervised input port settings from the device. This applies to the device such as CS40, SIO2, and DM20 only.

### Declaration

```
#include "BS_API.h"

int BS2_GetInputConfig(void* context, uint32_t deviceId, BS2InputConfig* config);
```

[See BS2InputConfig Structure](#)

### Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *config* : Input port configurations pointer

### Return Value

If successfully done, BS\_SDK\_SUCCESS will be returned.  
If there is an error, the corresponding error code will be returned.

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2\\_getinputconfig](http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getinputconfig)

Last update: **2020/09/29 10:55**