

Table of Contents

BS2_GetMifareCardConfigEx

Declaration

Parameter

Return Value

See Also

..... 1

..... 1

..... 1

..... 1

..... 1

[Configuration API](#) > [BS2_GetMifareCardConfigEx](#)

BS2_GetMifareCardConfigEx

[+ 2.9.9] Gets the configuration information used for AES128-encrypted Mifare cards on the device.

Warning

For enhanced security, key values cannot be obtained.

Declaration

```
#include "BS_API.h"

int BS2_GetMifareCardConfigEx(void* context, BS2_DEVICE_ID deviceId, const
BS2MifareCardConfigEx* config);
```

[See BS2MifareCardConfigEx Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device Identifier
- [Out] *config* : Pointer to set smart card information

Return Value

If successfully done, BS_SDK_SUCCESS will be returned. If there is an error, the corresponding error code will be returned.

See Also

[BS2_SetMifareCardConfigEx](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getmifarecardconfigex

Last update: **2025/06/11 16:10**