

Table of Contents

BS2_GetSystemExtConfig	1
Declaration	1
Parameter	1
Return Value	1

BS2_GetSystemExtConfig

Retrieves Master and slave device encryption settings from the device.

Declaration

```
#include "BS_API.h"

int BS2_GetSystemExtConfig(void* context, uint32_t deviceId,
BS2SystemConfigExt* config);
```

[See BS2SystemConfigExt Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *config* : Master and slave device encryption settings pointer

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getsystemextconfig&rev=1498615445

Last update: **2017/06/28 11:04**