

Table of Contents

BS2_GetSystemExtConfig

Declaration

Parameter

Return Value

..... 1
..... 1
..... 1
..... 1

BS2_GetSystemExtConfig

Retrieves Master and slave device encryption settings from the device.

IMPORTANT

You are not able to retrieve a key value due to security reason.

Declaration

```
#include "BS_API.h"

int BS2_GetSystemExtConfig(void* context, uint32_t deviceId,
BS2SystemConfigExt* config);
```

[See BS2SystemConfigExt Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *config* : Master and slave device encryption settings pointer

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.

If there is an error, the corresponding error code will be returned.

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2_getsystemextconfig&rev=1581987193

Last update: **2020/02/18 09:53**