Table of Contents

BS2_GetUserInfosFaceExFromDirWithKey

[+2.8.2] Gets the log after a given log record ID from the data extracted by USB by a maximum amount.
Supports USB files exported from FaceStaion F2 devices.

Declaration

```
#include "BS_API.h"

int BS2_GetUserInfosFaceExFromDirWithKey(void* context, const char* szDir,
char* uids, uint32_t uidCount, BS2UserFaceExBlob* userBlob, const
BS2EncryptKey* key);
```

View the structure of the BS2UserFaceExBlob

Parameters

- [In] *context* : Context
- [In] *szDir* : Data storage path
- [In] *uids* : List of user identifiers to be imported
- [In] *uidCount* : Number of user identifiers
- [Out] *userBlob* : Pointer to store user information
- [In] *key* : Encryption key and the key value specified by BS2_SetDataEncryptKey

Return value

Returns BS_SDK_SUCCESS if performed successfully, or a corresponding error code if an error occurs.

Watch Together

BS2_GetUserDatasFaceExFromDirWithKey

From:
<http://kb.supremainc.com/bs2sdk.> - **BioStar Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2_getuserinfosfaceexfromdirwithkey&rev=1650335289

Last update: **2022/04/19 11:28**