

Table of Contents

<i>BS2_GetUserList</i>	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

User Management API > BS2_GetUserList

BS2_GetUserList

Gets enrolled user ID as array. The size of the user ID is [BS2_USER_ID_SIZE](#).

Declaration

```
#include "BS_API.h"

int BS2_GetUserList(void* context, uint32_t deviceId, char** uidsObjs,
uint32_t* numUid, IsAcceptableUserID ptrIsAcceptableUserID);
```

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *uidsObjs* : Pointer to store the user ID list's address
- [Out] *numUid* : Number of users
- [In] *ptrIsAcceptableUserID* : TBD

NOTE

The *uidsObjs* variable needs to return the memory to the system by the [BS2_ReleaseObject](#) function after being used.

Return Value

If successfully done, [BS_SDK_SUCCESS](#) will be returned.

If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetUserInfos](#)

[BS2_EnrolUser](#)

[BS2_RemoveUser](#)

[BS2_RemoveAllUser](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getuserlist

Last update: **2016/08/03 13:11**