Table of Contents

Face API > BS2_RemoveAllAuthGroup

BS2_RemoveAllAuthGroup

Remove all authentication groups.

Declaration

```
#include "BS_API.h"

int BS2_RemoveAllAuthGroup(void* context, uint32_t deviceId);
```

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

BS2_GetAuthGroup
BS2_GetAllAuthGroup
BS2_SetAuthGroup
BS2_RemoveAuthGroup