

Table of Contents

BS2_SetEnableIPV4

Declaration

Parameter

Return Value

See Also

.....

.....

.....

.....

.....

1

1

1

1

1

[Communication API](#) > [BS2_SetEnableIPv4](#)

BS2_SetEnableIPv4

[+ 2.6.3] Sets IPv4 connection mode.

Declaration

```
#include "BS_API.h"

int BS2_SetEnableIPv4(void* context, int enable);
```

Parameter

- [In] *context* : Context
- [In] *enable* : Weather IPv4 connection is enabled

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetEnableIPv4](#)

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_setenableipv4

Last update: **2019/06/03 10:04**