

<b>BS2_GetFaceConfigExt</b>	.....	1
.....	.....	1
.....	.....	1
.....	.....	1
.....	.....	1

Configuration API > BS2\_GetFaceConfigExt

## BS2\_GetFaceConfigExt

[ + 2.7.1 ]

가

```
#include "BS_API.h"

int BS2_GetFaceConfigExt(void* context, uint32_t deviceId, BS2FaceConfigExt*
config);
```

BS2FaceConfigExt

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* :

BS\_SDK\_SUCCESS

, 가

From:

<http://kb.supremainc.com/bs2sdk/> - BioStar 2 Device SDK

Permanent link:

[http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2\\_getfaceconfigext](http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getfaceconfigext)

Last update: 2024/05/28 18:53