

**BS2\_GetSystemExtConfig** ..... 1  
..... 1  
..... 1  
..... 1

# BS2\_GetSystemExtConfig

Master Slave 가



```
#include "BS_API.h"

int BS2_GetSystemExtConfig(void* context, uint32_t deviceId,
BS2SystemConfigExt* config);
```

BS2SystemConfigExt

- [In] *context* : Context
- [In] *deviceId* :
- [In] *config* : Master Slave

BS\_SDK\_SUCCESS , 가

From: <http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link: [http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2\\_getsystemextconfig](http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getsystemextconfig)

Last update: **2020/02/12 15:59**