

BS2_GetSystemExtConfig 1
..... 1
..... 1
..... 1

BS2_GetSystemExtConfig

Master Slave 가

```
#include "BS_API.h"

int BS2_GetSystemExtConfig(void* context, uint32_t deviceId,
BS2SystemConfigExt* config);
```

BS2SystemConfigExt

- [In] *context* : Context
- [In] *deviceId* :
- [In] *config* : Master Slave

BS_SDK_SUCCESS , 가

From:
<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getsystemextconfig&rev=1498616787

Last update: **2017/06/28 11:26**