

BS2_GetTNAConfig 1
..... 1
..... 1
..... 1

BS2_GetTNAConfig

T&A 가 .

```
#include "BS_API.h"

int BS2_GetTNAConfig(void* context, uint32_t deviceId, BS2TNAConfig* config);
```

BS2TNAConfig

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* : TNA

BS_SDK_SUCCESS , 가

From: <http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link: http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_gettnaconfig

Last update: **2016/07/12 09:33**