

BS2_GetUserDatabaseInfoFromDir 1
..... 1
..... 1
..... 1
..... 1

BS2_GetUserDatabaseInfoFromDir

Usb Data (, , ,) 가 .

```
#include "BS_API.h"

int BS2_GetUserDatabaseInfoFromDir(void* context, const char* szDir,
uint32_t* numUsers, uint32_t* numCards, uint32_t* numFingers, uint32_t*
numFaces, IsAcceptableUserID ptrIsAcceptableUserID);
```

- [In] *context* : Context
- [Out] *szDir* : Data
- [Out] *numUsers* :
- [Out] *numCards* :
- [Out] *numFingers* :
- [Out] *numFaces* :
- [In] *ptrIsAcceptableUserID* : TBD



BS_SDK_SUCCESS , 가

- [BS2_AllocateUsbContext](#)
- [BS2_ReleaseUsbContext](#)
- [BS2_GetUserListFromDir](#)
- [BS2_GetUserInfosFromDir](#)
- [BS2_GetUserDatasFromDir](#)
- [BS2_GetUserInfosExFromDir](#)

[BS2_GetUserDatasExFromDir](#)
[BS2_GetLogFromDir](#)
[BS2_GetLogBlobFromDir](#)
[BS2_GetFilteredLogFromDir](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getuserdatabaseinfofromdir&rev=1540861290

Last update: **2018/10/30 10:01**