

BS2_GetUserDatasFromDir

.....

.....

.....

.....

.....

.....

1

1

1

1

1

[USB Exported Control API](#) > [BS2_GetUserDatasFromDir](#)

BS2_GetUserDatasFromDir

[+ 2.5.0] USB Data UserMask ID 가 .

```
#include "BS_API.h"

int BS2_GetUserDatasFromDir(void* context, const char* szDir, char* uids,
uint32_t uidCount, BS2UserBlob* userBlob, BS2_USER_MASK userMask);
```

BS2UserBlob

- [In] *context* : Context
- [In] *szDir* : Data
- [In] *uids* : 가
- [In] *uidCount* :
- [Out] *userBlob* :
- [In] *userMask* : Mask

BS_SDK_SUCCESS , 가

[BS2_AllocateUsbContext](#)
[BS2_ReleaseUsbContext](#)
[BS2_GetUserDatabaseInfoFromDir](#)
[BS2_GetUserListFromDir](#)
[BS2_GetUserInfosFromDir](#)
[BS2_GetUserInfosExFromDir](#)
[BS2_GetUserDatasExFromDir](#)
[BS2_GetLogFromDir](#)
[BS2_GetLogBlobFromDir](#)

BS2_GetFilteredLogFromDir

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getuserdatasfromdir&rev=1540884225

Last update: **2018/10/30 16:23**