

BS2_GetUserInfosFromDir 1

..... 1

..... 1

..... 1

..... 1

BS2_GetUserInfosFromDir

[+ 2.5.0] USB

Data

가

.

```
#include "BS_API.h"

int BS2_GetUserInfosFromDir(void* context, const char* szDir, char* uids,
uint32_t uidCount, BS2UserBlob* userBlob);
```

BS2UserBlob

- [In] *context* : Context
- [In] *szDir* : Data
- [In] *uids* : 가
- [In] *uidCount* :
- [Out] *userBlob* :

BS_SDK_SUCCESS

,

가

.

- [BS2_AllocateUsbContext](#)
- [BS2_ReleaseUsbContext](#)
- [BS2_GetUserDatabaseInfoFromDir](#)
- [BS2_GetUserListFromDir](#)
- [BS2_GetUserDatasFromDir](#)
- [BS2_GetUserInfosExFromDir](#)
- [BS2_GetUserDatasExFromDir](#)
- [BS2_GetLogFromDir](#)
- [BS2_GetLogBlobFromDir](#)
- [BS2_GetFilteredLogFromDir](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getuserinfosfromdir

Last update: **2018/10/30 16:24**