

BS2_GetUserInfosFromDir

.....

1

.....

1

.....

1

.....

1

.....

1

User Management API > [BS2_GetUserInfosFromDir](#)

BS2_GetUserInfosFromDir

Usb Data 가 .

```
#include "BS_API.h"
```

```
int BS2_GetUserInfosFromDir(void* context, const char* szDir, char* uids,
uint32_t uidCount, BS2UserBlob* userBlob);
```

BS2UserBlob

- [In] *context* : Context
- [In] *szDir* : Data
- [In] *uids* : 가
- [In] *uidCount* :
- [Out] *userBlob* :

BS_SDK_SUCCESS , 가

[BS2_GetUserDatabaseInfoFromDir](#)

[BS2_GetUserListFromDir](#)

[BS2_GetUserDatasFromDir](#)

[BS2_GetUserInfosExFromDir](#)

[BS2_GetUserDatasExFromDir](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getuserinfosfromdir&rev=1504615742

Last update: **2017/09/05 21:49**