BS2_GetUserList 1

User Management API > BS2_GetUserList

BS2_GetUserList

.   BS2_USER_ID_SIZE   .

```
#include "BS_API.h"

int BS2_GetUserList(void* context, uint32_t deviceId, char** uidsObjs,
uint32_t* numUid, IsAcceptableUserID ptrIsAcceptableUserID);
```

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *uidsObjs* :
- [Out] *numUid* :
- [In] *ptrIsAcceptableUserID* : TBD

  uidsObjs   BS2_ReleaseObject
                     .

               BS_SDK_SUCCESS   ,
       .

BS2_GetUserList
BS2_RemoveUser
BS2_RemoveAllUser BS2_GetUserInfos
BS2_GetUserInfosEx
BS2_EnrolUser
BS2_EnrolUserEx
BS2_GetUserDatas
BS2_GetUserDatasEx

From:
<http://kb.supremainc.com/bs2sdk./> - **BioStar Device SDK**

Permanent link:
<http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getuserlist&rev=1540949459>

Last update: **2018/10/31 10:30**