

**BS2\_SetFacilityCodeConfig** ..... 1  
..... 1  
..... 1  
..... 1  
..... 1

# BS2\_SetFacilityCodeConfig

[+ 2.9.9] Door Interface(DI-24) OSDP  
BS2FacilityCode .

```
#include "BS_API.h"

int BS2_SetFacilityCodeConfig(void* context, BS2_DEVICE_ID deviceId,
BS2FacilityCodeConfig* config);
```

BS2FacilityCodeConfig

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* : BS2FacilityCodeConfig

BS\_SDK\_SUCCESS , 가

## BS2\_GetFacilityCodeConfig

From:  
<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:  
[http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2\\_setfacilitycodeconfig](http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_setfacilitycodeconfig)

Last update: **2025/06/11 13:37**