

BS2_SetInputConfig 1
..... 1
..... 1
..... 1

BS2_SetInputConfig

```
#include "BS_API.h"

int BS2_SetInputConfig(void* context, uint32_t deviceId, BS2InputConfig* config);
```

BS2InputConfig

- [In] *context* : Context
- [In] *deviceId* :
- [In] *config* :

BS_SDK_SUCCESS , 가

From:
<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_setinputconfig&rev=1468283189

Last update: **2016/07/12 09:26**