

**BS2\_SetRS485ConfigEx** ..... 1  
..... 1  
..... 1  
..... 1

## BS2\_SetRS485ConfigEx

RS485

```
#include "BS_API.h"

int BS2_SetRS485ConfigEx(void* context, uint32_t deviceId, BS2Rs485ConfigEX* config);
```

BS2Rs485ConfigEX

- [In] *context* : Context
- [In] *deviceId* :
- [In] *config* : RS485

BS\_SDK\_SUCCESS , 가

From:  
<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:  
[http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2\\_setrs485configex](http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_setrs485configex)

Last update: **2017/08/29 10:05**