

BS2_GetFactoryConfig	1
	1
	1
	1

Configuration API > BS2_GetFactoryConfig

BS2_GetFactoryConfig

가

```
#include "BS_API.h"

int BS2_GetFactoryConfig(void* context, uint32_t deviceId, BS2FactoryConfig*
config);
```

BS2FactoryConfig

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* :

BS_SDK_SUCCESS , 가

From:
<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getfactoryconfig

Last update: **2016/07/12 09:49**