

<b>BS2_GetWiegandDeviceConfig</b>	.....	1
	.....	1
	.....	1
	.....	1

Configuration API > BS2\_GetWiegandDeviceConfig

## BS2\_GetWiegandDeviceConfig

Wiegand

가 .

```
#include "BS_API.h"

int BS2_GetWiegandDeviceConfig(void* context, uint32_t deviceId,
BS2WiegandDeviceConfig* config);
```

BS2WiegandDeviceConfig

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* : Wiegand

BS\_SDK\_SUCCESS , 가

From:

<http://kb.supremainc.com/bs2sdk/> - BioStar 2 Device SDK

Permanent link:

[http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2\\_getwieganddeviceconfig](http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getwieganddeviceconfig)

Last update: 2016/07/12 09:19