

Table of Contents

BS2_GetConfig	1
Declaration	1
Parameter	1
Return Value	1

BS2_GetConfig

Retrieves configuration blob from the device.

Declaration

```
#include "BS_API.h"

int BS2_GetConfig(void* context, uint32_t deviceId, BS2Configs* configs);
```

[See BS2Configs Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *configs* : Configuration blob

NOTE

If the configMask from the configs is not supported from the device, an error will be returned.

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getconfig

Last update: **2016/07/12 09:16**