Table of Contents

Device API > BS2_GetDeviceTime

BS2_GetDeviceTime

Gets the device's current time

Declaration

```
#include "BS_API.h"

int BS2_GetDeviceTime(void* context, BS2_DEVICE_ID deviceId, BS2_TIMESTAMP*
gmtTime);
```

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *gmtTime* : Pointer to store GMT(UTC+0) time.

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

BS2_SetDeviceTime