

BS2_GetDataEncryptKey

.....

.....

.....

.....

.....

.....

1

1

1

1

1

SDK API > BS2_GetDataEncryptKey

BS2_GetDataEncryptKey

[] 가 .

--

```
#include "BS_API.h"
```

```
int BS2_GetDataEncryptKey(void* context, uint32_t deviceId, BS2EncryptKey* keyInfo);
```

BS2EncryptKey

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *keyInfo* :

BS SDK SUCCESS , 가

BS2_SetDataEncryptKey

BS2_RemoveDataEncryptKey

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getdataencryptkey&rev=1600770177

Last update: **2020/09/22 19:22**