Configuration API > BS2_GetRtspConfig

BS2_GetRtspConfig

[+ 2.8.3] RTSP .

```
#include "BS_API.h"

int BS2_GetRtspConfig(void* context, uint32_t deviceId, BS2RtspConfig*
config);
```

> BS2RtspConfig

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* : RTSP

BS_SDK_SUCCESS ,

.

From:
http://kb.supremainc.com/bs2sdk/ - **BioStar Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getrtspconfig

Last update: **2024/05/28 19:04**