

BS2_GetUserDatasExFromDir 1

..... 1

..... 1

..... 2

..... 2

BS2_GetUserDatasExFromDir

[+ 2.5.0] USB Data 가 .

```
#include "BS_API.h"

int BS2_GetUserDatasExFromDir(void* context, const char* szDir, char* uids,
uint32_t uidCount, BS2UserBlobEx* userBlob, BS2_USER_MASK userMask);
```

BS2UserBlobEx

- [In] *context* : Context
- [In] *szDir* : Data
- [In] *uids* : 가
- [In] *uidCount* :
- [Out] *userBlob* :
- [In] *userMask* : Mask

0x0000	
0x0001	data
0x0002	
0x0004	
0x0008	
0x0010	PIN
0x0020	
0x0040	
0x0080	
0x0100	
0x0200	
0x0400	
0x0800	(FaceStation F2)
0x1000	(FaceStation F2)
0xFFFF	

BS_SDK_SUCCESS , 가

- BS2_AllocateUsbContext
- BS2_ReleaseUsbContext
- BS2_GetUserDatabaseInfoFromDir
- BS2_GetUserListFromDir
- BS2_GetUserInfosFromDir
- BS2_GetUserDatasFromDir
- BS2_GetUserInfosExFromDir
- BS2_GetLogFromDir
- BS2_GetLogBlobFromDir
- BS2_GetFilteredLogFromDir

From:
<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getuserdatasexfromdir

Last update: **2020/08/21 11:48**