

BS2_GetUserInfosExFromDir 1

..... 1

..... 1

..... 1

..... 1

BS2_GetUserInfosExFromDir

Usb Data 가 .

```
#include "BS_API.h"

int BS2_GetUserInfosExFromDir(void* context, const char* szDir, char* uids,
uint32_t uidCount, BS2UserBlobEx* userBlob);
```

BS2UserBlobEx

- [In] *context* : Context
- [In] *szDir* : Data
- [In] *uids* : 가
- [In] *uidCount* :
- [Out] *userBlob* :

BS_SDK_SUCCESS , 가

- BS2_AllocateUsbContext
- BS2_ReleaseUsbContext
- BS2_GetUserDatabaseInfoFromDir
- BS2_GetUserListFromDir
- BS2_GetUserInfosFromDir
- BS2_GetUserDatasFromDir
- BS2_GetUserDatasExFromDir
- BS2_GetLogFromDir
- BS2_GetLogBlobFromDir
- BS2_GetFilteredLogFromDir

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getuserinfosexfromdir&rev=1540861360

Last update: **2018/10/30 10:02**