

BS2_GetUserListFromDir 1
..... 1
..... 1
..... 1
..... 1

BS2_GetUserListFromDir

Usb Data 가 .

```
#include "BS_API.h"

int BS2_GetUserListFromDir(void* context, const char* szDir, char** uidsObj,
uint32_t* numUid, IsAcceptableUserID ptrIsAcceptableUserID);
```

- [In] *context* : Context
- [Out] *szDir* : Data
- [Out] *uidsObjs* :
- [Out] *numUid* :
- [In] *ptrIsAcceptableUserID* : TBD



BS_SDK_SUCCESS , 가

- [BS2_GetUserDatabaseInfoFromDir](#)
- [BS2_GetUserInfosFromDir](#)
- [BS2_GetUserDatasFromDir](#)
- [BS2_GetUserInfosExFromDir](#)
- [BS2_GetUserDatasExFromDir](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getuserlistfromdir&rev=1504615715

Last update: **2017/09/05 21:48**